

BRIEFING

~~(786) Particle Size Distribution Estimation by Analytical Sieving, USP 27 page 2335 and page 1581 of PF 28(5) [Sept.–Oct. 2002]. The United States Pharmacopeia is the coordinating pharmacopeia for the international harmonization of compendial standards for this chapter. The revisions presented in this proposal represents the **ADOPTION STAGE 6** draft and have been accepted by the members of the Pharmacopeial Discussion Group. Major changes from the current USP General Chapter include the omission of the section on the *Wet Sieving Method*, because it is not adequate or practical for pharmaceutical powders. Other minor changes and editorial changes are included.~~

(ETM: J. Lane) RTS—41729-2

Change to read:

~~(786) PARTICLE SIZE DISTRIBUTION ESTIMATION BY ANALYTICAL SIEVING~~

~~Sieving is one of the oldest methods of classifying powders by particle size distribution. Sieving is most suitable where the majority of the particles are larger than about 75 µm, although it can be used for some powders having smaller particle sizes where the method can be validated. In pharmaceutical terms, sieving is usually the method of choice for classification of the coarser grades of single powders. It is a particularly attractive method in that powders are classified only on the basis of particle size, and in most cases the analysis can be carried out in the dry state.~~

~~Among the limitations of the sieving method are the need for an appreciable amount of sample (normally at least 25 g) and difficulty in sieving oily or other cohesive powders that tend to clog the sieve openings. The method is essentially a two-dimensional estimate of size because passage through the sieve aperture is frequently more dependent on maximum width and thickness than on length.~~

~~This method is intended for estimation of the total particle size distribution of a single material. It is not intended for determination of the proportion of particles passing or retained on one or two sieves.~~

~~Estimate the particle size distribution as described under *Method I*, unless otherwise specified in the individual monograph. *Method I* is the dry sieving method. Where difficulty is experienced in reaching the endpoint (i.e., material does not readily pass through the sieves) or when it is necessary to use the finer end of the sieving range (below 75 µm), *Method II*, which is a wet sieving technique, may be used; however, in the latter case serious consideration should be given to the use of an alternative particle-sizing method.~~

~~**Principles of Analytical Sieving**—Analytical test sieves are constructed from a woven wire mesh, which is of simple weave that is assumed to give nearly square apertures and is sealed into the base of an open cylindrical container. The basic analytical method involves stacking the sieves on top of one another in ascending degrees of coarseness, and then placing the test powder on the top sieve.~~

~~The nest of sieves is subjected to a standardized period of agitation, and then the weight of material retained on each sieve is accurately determined. The test gives the weight percentage of powder in each sieve size range.~~

~~This sieving process for estimating the particle size distribution of a single pharmaceutical powder is generally intended for use where at least 80% of the particles are larger than 75 µm. The size parameter involved in determining particle size distribution by analytical sieving is the *length of the side of the minimum square aperture through which the particle will pass.*~~

TEST SIEVES

Test sieves suitable for pharmacopeial tests conform to the most current edition of International Organization for Standardization Specification ISO 3310-1: Test sieves—Technical requirements and Testing ¹ (see Table 1). Unless otherwise specified in the monograph, use those ISO sieves listed as principal sizes in Table 1.

Table 1. Sizes of Standard Sieve Series in Range of Interest ²

ISO Nominal Aperture			US Sieve No.	Recommended USP Sieves	European Sieve No.	Japan Sieve No.
Principal sizes	Supplementary sizes					
R-20/3	R-20	R-40/3				
11.20 mm	11.20 mm	11.20 mm			11200	
	10.00 mm					
		9.50 mm				
	9.00 mm					
8.00 mm	8.00 mm	8.00 mm				
	7.10 mm					
		6.70 mm				
	6.30 mm					
5.60 mm	5.60 mm	5.60 mm			5600	3.5
	5.00 mm					
		4.75 mm				4
	4.50 mm					
4.00 mm	4.00 mm	4.00 mm	5	4000	4000	4.7
	3.55 mm					
		3.35 mm	6			5.5
	3.15 mm					
2.80 mm	2.80 mm	2.80 mm	7	2800	2800	6.5
	2.50 mm					
		2.36 mm	8			7.5
	2.24 mm					
2.00 mm	2.00 mm	2.00 mm	10	2000	2000	8.6
	1.80 mm					
		1.70 mm	12			10
	1.60 mm					
1.40 mm	1.40 mm	1.40 mm	14	1400	1400	12
	1.25 mm					
		1.18 mm	16			14
	1.12 mm					
1.00 mm	1.00 mm	1.00 mm	18	1000	1000	16
	900 µm					
		850 µm	20			18
	800 µm					
710 µm	710 µm	710 µm	25	710	710	22

ISO Nominal Aperture			US Sieve No.	Recommended USP Sieves	European Sieve No.	Japan Sieve No.
Principal sizes	Supplementary sizes					
R 20/3	R 20	R 40/3				
	630 μm					
		600 μm	30			26
	560 μm					
500 μm	500 μm	500 μm	35	500	500	30
	450 μm					
		425 μm	40			36
	400 μm					
355 μm	355 μm	355 μm	45	355	355	42
	315 μm					
		300 μm	50			50
	280 μm					
250 μm	250 μm	250 μm	60	250	250	60
	224 μm					
		212 μm	70			70
	200 μm					
180 μm	180 μm	180 μm	80	180	180	83
	160 μm					
		150 μm	100			100
	140 μm					
125 μm	125 μm	125 μm	120	125	125	119
	112 μm					
		106 μm	140			140
	100 μm					
90 μm	90 μm	90 μm	170	90	90	166
	80 μm					
		75 μm	200			200
	71 μm					
63 μm	63 μm	63 μm	230	63	63	235
	56 μm					
		53 μm	270			282
	50 μm					
45 μm	45 μm	45 μm	325	45	45	330
	40 μm					
		38 μm			38	391

² The specifications for standard sieves in Europe, Japan, and the US are all identical to ISO 3310-1:2000(E). The lists of European and Japanese standard sieves are included for informational purposes.

Sieves are selected to cover the entire range of particle sizes present in the test specimen. This nest of sieves is completed by a well fitting collecting pan at its base and lid at its top. Use micrometers or millimeters in denoting test sieve openings. [NOTE — Mesh numbers are provided in the table for

~~conversion purposes only.] Test sieves are made from stainless steel or, less preferably, from brass or other suitable nonreactive wire.~~

~~Calibration and recalibration of test sieves is in accordance with the most current edition of ISO 3310-1. Sieves should be carefully examined for gross distortions and fractures, especially at their screen frame joints, before use. Sieves may be calibrated optically to estimate the average opening size, and opening variability, of the sieve mesh. Alternatively, for the evaluation of the effective opening of test sieves in the size range of 212 to 850 μm , Standard Glass Spheres are available from the National Institute of Standards and Technology as Standard Reference Material 1018. Unless otherwise specified in the individual monograph, perform the sieve analysis at controlled room temperature and a relative humidity between 20% and 70%.~~

~~*Cleaning Test Sieves*—Ideally, test sieves should be cleaned using only an air jet or a liquid stream. If some apertures remain blocked by test particles, careful gentle brushing may be used as a last resort. Washing sieves in hot water is not recommended since the sieves can distort and rupture during heating and cooling. If it is necessary to use water, it should be used at ambient temperature and the sieve dried by first using a volatile water-miscible solvent to remove the water and then a low-pressure air jet to remove the solvent. This procedure should be carried out in a fume hood or cabinet that conforms to local regulations.~~

~~**Test Specimen**—If the test specimen weight is not given in the monograph for a particular material, use a test specimen having a weight between 25 and 100 g, depending on the bulk density of the material, and test sieves having a 200-mm diameter. Determine the most appropriate weight for a given material by test sieving accurately weighed specimens of different weights, such as 25, 50, and 100 g, for the same time period on a mechanical shaker. [NOTE—If the test results are similar for the 25-g and 50-g specimens, but the 100-g specimen shows a lower percentage through the finest sieve, the 100-g specimen size is too large.] Where only a specimen of 10 to 25 g is available, smaller diameter test sieves conforming to the same ISO mesh specifications may be substituted, but the endpoint must be redetermined.~~

~~If the test material is prone to picking up or losing significant amounts of water with varying humidity, the test must be carried out in an appropriately controlled environment. Similarly, if the test material is known to develop an electrostatic charge, careful observation must be made to ensure that such charging is not influencing the analysis. If both of the above effects cannot be eliminated, an alternative particle-sizing technique must be selected.~~

~~**Agitation Methods**—Use a mechanical device that imparts either a rotating tap (200 to 300 horizontal revolutions and 140 to 300 taps per minute) or vibratory (1 to 2 mm amplitude) motion to the sieves as the reference method of agitating test sieves, unless otherwise stated in the individual monograph. Methods utilizing entrainment of the particles in an air stream may also be used. The results must indicate the type of sieving method used.~~

~~**Endpoint Determination**—The test sieving analysis is complete when the weight on any of the test sieves does not change by more than 5% (10% in the case of 76-mm sieves) of the previous weight on that sieve. If less than 5% of the total specimen weight is present on a given sieve, the endpoint for that sieve is increased to a weight change of not more than 20% of the previous weight on that sieve.~~

~~If more than 50% of the total specimen weight is found on any one sieve, the test should be repeated, but with the addition to the sieve nest of the next coarsest sieve to that carrying the excessive weight, i.e., addition of the ISO series sieve omitted from the USP series in Table 1. For example, if more than 50% of the total specimen weight is found on the 180 μm sieve, the ISO 212 μm sieve should be placed between the 180 μm and 250 μm sieves in the sieve nest.~~

SIEVING METHODS

Method I (Dry Sieving Method)—Tare each test sieve to the nearest 0.1 g. Place an accurately weighed quantity of test specimen on the top (coarsest) sieve, and replace the lid. Agitate the nest of sieves for 5 minutes. Then carefully remove each from the nest without loss of material. Reweigh each sieve, and determine the weight of material on each sieve. Determine the weight of material in the collecting pan in a similar manner. Reassemble the nest of sieves, and agitate for 5 minutes. Remove and weigh each sieve as previously described. Repeat these steps until the endpoint criteria are met (see *Endpoint Determination* under *Test Sieves*). Upon completion of the analysis, reconcile the weights of material. Total losses must not exceed 5% of the weight of the original test specimen.

Repeat the analysis with a fresh specimen, but using a single sieving time equal to that of the combined times used above. Confirm that this sieving time conforms to the requirements for endpoint determination. When this endpoint has been validated for a specific material, then a single fixed time of sieving may be used for future analyses, providing the particle size distribution does not change significantly.

If there is evidence that the particles retained on any sieve are aggregates rather than single particles, the use of dry sieving is unlikely to give good reproducibility, and *Method II* should be considered as one preferred technique.

Method II (Wet Sieving Method)—Modify the lid and collecting pan of the sieve nest to permit addition of a liquid onto the surface of the top sieve and collection of the liquid from the pan. Dry a sufficient quantity of the test material to constant weight at a temperature that will not have a detrimental effect on the material, e.g., if it is a solvate. Select a liquid in which the test specimen is insoluble, and modify the sieving method as indicated below. Thoroughly disperse the dried test material in the liquid by gentle agitation, and pour this dispersion onto the top sieve. Rinse the dispersion equipment with fresh liquid, and add the rinsings to the top sieve. Feed the sieving liquid through a suitable pumping mechanism to the nozzle(s) in the lid, and collect the sieving liquid from the pan in a suitable container. Continue the wet sieving process until the emerging liquid appears free of particles.

Remove each sieve from the sieve nest, and dry each sieve to constant weight at the same temperature as that used above. Determine the weight of dried material on each sieve.

Air Jet and Sonic Sifter Sieving—Different types of commercial equipment that use a moving air current are available for sieving. A system that uses a single sieve at a time is referred to as *air jet* sieving. It uses the same general sieving methodology as that described under *Method I*, but with a standardized air jet replacing the normal agitation mechanism. It requires sequential analyses on individual sieves to provide a particle size distribution. This technique is more suitable where only oversize or undersize fractions are needed.

In the *sonic sifting* method, a nest of sieves is used, and the test specimen is carried in a vertically oscillating column of air that lifts the specimen and then carries it back against the mesh openings at a given number of pulses per minute. The air jet sieving and sonic sieving methods may be useful when the standard dry and wet sieving techniques are incapable of giving a meaningful analysis.

These methods are highly dependent upon proper dispersion of the powder in the air current. This requirement may be hard to achieve if the method is used at the lower end of the sieving range (i.e., below 75 μm), when the particles tend to be more cohesive, and especially if there is any tendency for the material to develop an electrostatic charge. In the latter case an antistatic agent, such as silicon dioxide or aluminum oxide, may be added at the 0.5% (w/w) level to minimize this effect. For the

~~above reasons endpoint determination is particularly critical, and it is very important to confirm that the oversize material is in fact single particles and is not composed of aggregates.~~

INTERPRETATION

~~The raw data must include the weight of test specimen, the total sieving time, and the precise sieving methodology, in addition to the weights on the individual sieves and in the pan. It may be convenient to convert the raw data into a cumulative weight distribution, and if it is desired to express the distribution in terms of a cumulative weight undersize, the range of sieves used should include a sieve through which all the material passes. If there is evidence on any of the test sieves that the material remaining on it is composed of aggregates formed during the sieving process, the analysis is invalid.~~

~~± ISO 3310 1:2000(E) analytical sieve specifications are identical to those of the appropriate nominal aperture in ASTM E11-01 US Standard Sieve Series.~~

Add the following:**■ <786> PARTICLE SIZE DISTRIBUTION ESTIMATION BY ANALYTICAL SIEVING**

Sieving is one of the oldest methods of classifying powders and granules by particle size distribution. When using a woven sieve cloth, the sieving will essentially sort the particles by their intermediate size dimension (i.e., breadth or width). Mechanical sieving is most suitable where the majority of the particles are larger than about 75 μm . For smaller particles, the light weight provides insufficient force during sieving to overcome the surface forces of cohesion and adhesion that cause the particles to stick to each other and to the sieve, and thus cause particles that would be expected to pass through the sieve to be retained. For such materials other means of agitation such as air-jet sieving or sonic sifting may be more appropriate. Nevertheless, sieving can sometimes be used for some powders or granules having median particle sizes smaller than 75 μm where the method can be validated. In pharmaceutical terms, sieving is usually the method of choice for classification of the coarser grades of single powders or granules. It is a particularly attractive method in that powders and granules are classified only on the basis of particle size, and in most cases the analysis can be carried out in the dry state.

Among the limitations of the sieving method are the need for an appreciable amount of sample (normally at least 25 g, depending on the density of the powder or granule, and the diameter of test sieves) and difficulty in sieving oily or other cohesive powders or granules that tend to clog the sieve openings. The method is essentially a two-dimensional estimate of size because passage through the sieve aperture is frequently more dependent on maximum width and thickness than on length.

This method is intended for estimation of the total particle size distribution of a single material. It is not intended for determination of the proportion of particles passing or retained on one or two sieves.

Estimate the particle size distribution as described under *Dry Sieving Method*, unless otherwise specified in the individual monograph. Where difficulty is experienced in reaching the endpoint (i.e., material does not readily pass through the sieves) or when it is necessary to use the finer end of the sieving range (below 75 μm), serious consideration should be given to the use of an alternative particle-sizing method.

Sieving should be carried out under conditions that do not cause the test sample to gain or lose moisture. The relative humidity of the environment in which the sieving is carried out should be controlled to prevent moisture uptake or loss by the sample. In the absence of evidence to the contrary, analytical test sieving is normally carried at ambient humidity. Any special conditions that apply to a particular material should be detailed in the individual monograph.

Principles of Analytical Sieving— Analytical test sieves are constructed from a woven-wire mesh, which is of simple weave that is assumed to give nearly square apertures and is sealed into the base of an open cylindrical container. The basic analytical method involves stacking the sieves on top of one another in ascending degrees of coarseness, and then placing the test powder on the top sieve.

The nest of sieves is subjected to a standardized period of agitation, and then the weight of material retained on each sieve is accurately determined. The test gives the weight percentage of powder in each sieve size range.

This sieving process for estimating the particle size distribution of a single pharmaceutical powder is generally intended for use where at least 80% of the particles are larger than 75 μm . The size parameter involved in determining particle size distribution by analytical sieving is the length of the side of the minimum square aperture through which the particle will pass.

TEST SIEVES

Test sieves suitable for pharmacopeial tests conform to the most current edition of International Organization for Standardization Specification ISO 3310-1: Test Sieves—Technical Requirements and Testing (see *Table 1*). Unless otherwise specified in the monograph, use those ISO sieves listed as principal sizes in *Table 1*. Unless otherwise specified in the monograph, use those ISO sieves listed in *Table 1* as recommended in the particular region.

Table 1. Sizes of Standard Sieve Series in Range of Interest

ISO Nominal Aperture			US Sieve No.	Recommended USP Sieves (mesh)	European Sieve No.	Japan Sieve No.
<u>Principal Sizes</u>	<u>Supplementary Sizes</u>					
R 20/3	R 20	R 40/3				
11.20 mm	11.20 mm	11.20 mm			11200	
	10.00 mm					
		9.50 mm				
	9.00 mm					
8.00 mm	8.00 mm	8.00 mm				
	7.10 mm					
		6.70 mm				
	6.30 mm					
5.60 mm	5.60 mm	5.60 mm			5600	3.5
	5.00 mm					
		4.75 mm				4
	4.50 mm					
4.00 mm	4.00 mm	4.00 mm	5	4000	4000	4.7
	3.55 mm					
		3.35 mm	6			5.5
	3.15 mm					
2.80 mm	2.80 mm	2.80 mm	7	2800	2800	6.5
	2.50 mm					

ISO Nominal Aperture			US Sieve No.	Recommended USP Sieves (mesh)	European Sieve No.	Japan Sieve No.
Principal Sizes	Supplementary Sizes					
R 20/3	R 20	R 40/3				
		2.36 mm	8			7.5
	2.24 mm					
2.00 mm	2.00 mm	2.00 mm	10	2000	2000	8.6
	1.80 mm					
		1.70 mm	12			10
	1.60 mm					
1.40 mm	1.40 mm	1.40 mm	14	1400	1400	12
	1.25 mm					
		1.18 mm	16			14
	1.12 mm					
1.00 mm	1.00 mm	1.00 mm	18	1000	1000	16
	900 µm					
		850 µm	20			18
	800 µm					
710 µm	710 µm	710 µm	25	710	710	22
	630 µm					
		600 µm	30			26
	560 µm					
500 µm	500 µm	500 µm	35	500	500	30
	450 µm					
		425 µm	40			36
	400 µm					
355 µm	355 µm	355 µm	45	355	355	42
	315 µm					
		300 µm	50			50
	280 µm					
250 µm	250 µm	250 µm	60	250	250	60
	224 µm					
		212 µm	70			70
	200 µm					
180 µm	180 µm	180 µm	80	180	180	83

ISO Nominal Aperture			US Sieve No.	Recommended USP Sieves (mesh)	European Sieve No.	Japan Sieve No.
Principal Sizes	Supplementary Sizes					
R 20/3	R 20	R 40/3				
	160 µm					
		150 µm	100			100
	140 µm					
125 µm	125 µm	125 µm	120	125	125	119
	112 µm					
		106 µm	140			140
	100 µm					
90 µm	90 µm	90 µm	170	90	90	166
	80 µm					
		75 µm	200			200
	71 µm					
63 µm	63 µm	63 µm	230	63	63	235
	56 µm					
		53 µm	270			282
	50 µm					
45 µm	45 µm	45 µm	325	45	45	330
	40 µm					
		38 µm			38	391

Sieves are selected to cover the entire range of particle sizes present in the test specimen. A nest of sieves having a $\sqrt{2}$ progression of the area of the sieve openings is recommended. The nest of sieves is assembled with the coarsest screen at the top and the finest at the bottom. Use micrometers or millimeters in denoting test sieve openings. [NOTE— Mesh numbers are provided in the table for conversion purposes only.] Test sieves are made from stainless steel or, less preferably, from brass or other suitable nonreactive wire.

Calibration and recalibration of test sieves is in accordance with the most current edition of ISO 3310-1. Sieves should be carefully examined for gross distortions and fractures, especially at their screen frame joints, before use. Sieves may be calibrated optically to estimate the average opening size, and opening variability, of the sieve mesh. Alternatively, for the evaluation of the effective opening of test sieves in the size range of 212 to 850 µm, Standard Glass Spheres are available. Unless otherwise specified in the individual monograph, perform the sieve analysis at controlled room temperature and at ambient relative humidity.

Cleaning Test Sieves— Ideally, test sieves should be cleaned using only an air jet or a liquid stream. If some apertures remain blocked by test particles, careful gentle brushing may be used as a last resort.

Test Specimen— If the test specimen weight is not given in the monograph for a particular material, use a test specimen having a weight between 25 and 100 g, depending on the bulk density of the material, and test sieves having a 200-mm diameter. For 76-mm sieves, the amount of material that can be accommodated is approximately 1/7th that which can be accommodated on a 200-mm sieve. Determine the most appropriate weight for a given material by test sieving accurately weighed specimens of different weights, such as 25, 50, and 100 g, for the same time period on a mechanical

shaker. [NOTE— If the test results are similar for the 25-g and 50-g specimens, but the 100-g specimen shows a lower percentage through the finest sieve, the 100-g specimen size is too large.] Where only a specimen of 10 to 25 g is available, smaller diameter test sieves conforming to the same mesh specifications may be substituted, but the endpoint must be re-determined. The use of test samples having a smaller mass (e.g. down to 5 g) may be needed. For materials with low apparent particle density, or for materials mainly comprising particles with a highly iso-diametrical shape, specimen weights below 5 g for a 200-mm screen may be necessary to avoid excessive blocking of the sieve. During validation of a particular sieve analysis method, it is expected that the problem of sieve blocking will have been addressed.

If the test material is prone to picking up or losing significant amounts of water with varying humidity, the test must be carried out in an appropriately controlled environment. Similarly, if the test material is known to develop an electrostatic charge, careful observation must be made to ensure that such charging is not influencing the analysis. An antistatic agent, such as colloidal silicon dioxide and/or aluminum oxide, may be added at a 0.5 percent (m/m) level to minimize this effect. If both of the above effects cannot be eliminated, an alternative particle-sizing technique must be selected.

Agitation Methods— Several different sieve and powder agitation devices are commercially available, all of which may be used to perform sieve analyses. However, the different methods of agitation may give different results for sieve analyses and endpoint determinations because of the different types and magnitude of the forces acting on the individual particles under test. Methods using mechanical agitation or electromagnetic agitation, and that can induce either a vertical oscillation or a horizontal circular motion, or tapping or a combination of both tapping and horizontal circular motion are available. Entrainment of the particles in an air stream may also be used. The results must indicate which agitation method was used and the agitation parameters used (if they can be varied), since changes in the agitation conditions will give different results for the sieve analysis and endpoint determinations, and may be sufficiently different to give a failing result under some circumstances.

Endpoint Determination— The test sieving analysis is complete when the weight on any of the test sieves does not change by more than 5% or 0.1 g (10% in the case of 76-mm sieves) of the previous weight on that sieve. If less than 5% of the total specimen weight is present on a given sieve, the endpoint for that sieve is increased to a weight change of not more than 20% of the previous weight on that sieve.

If more than 50% of the total specimen weight is found on any one sieve, unless this is indicated in the monograph, the test should be repeated, but with the addition to the sieve nest of a more coarse sieve intermediate between that carrying the excessive weight and the next coarsest sieve in the original nest, i.e., addition of the ISO series sieve omitted from the nest of sieves.

SIEVING METHODS

Mechanical Agitation

Dry Sieving Method— Tare each test sieve to the nearest 0.1 g. Place an accurately weighed quantity of test specimen on the top (coarsest) sieve, and replace the lid. Agitate the nest of sieves for 5 minutes. Then carefully remove each from the nest without loss of material. Reweigh each sieve, and determine the weight of material on each sieve. Determine the weight of material in the collecting pan in a similar manner. Reassemble the nest of sieves, and agitate for 5 minutes. Remove and weigh each sieve as previously described. Repeat these steps until the endpoint criteria are met (see *Endpoint Determination* under *Test Sieves*). Upon completion of the analysis, reconcile the weights of material. Total losses must not exceed 5% of the weight of the original test specimen.

Repeat the analysis with a fresh specimen, but using a single sieving time equal to that of the combined times used above. Confirm that this sieving time conforms to the requirements for endpoint determination. When this endpoint has been validated for a specific material, then a single fixed time of sieving may be used for future analyses, providing the particle size distribution falls within normal variation.

If there is evidence that the particles retained on any sieve are aggregates rather than single particles, the use of mechanical dry sieving is unlikely to give good reproducibility, a different particle size analysis method should be used.

Air Entrainment Methods

Air Jet and Sonic Sifter Sieving— Different types of commercial equipment that use a moving air current are available for sieving. A system that uses a single sieve at a time is referred to as air jet sieving. It uses the same general sieving methodology as that described under the *Dry Sieving Method*, but with a standardized air jet replacing the normal agitation mechanism. It requires sequential analyses on individual sieves starting with the finest sieve to obtain a particle size distribution. Air jet sieving often includes the use of finer test sieves than used in ordinary dry sieving. This technique is more suitable where only oversize or undersize fractions are needed.

In the sonic sifting method, a nest of sieves is used, and the test specimen is carried in a vertically oscillating column of air that lifts the specimen and then carries it back against the mesh openings at a given number of pulses per minute. It may be necessary to lower the sample amount to 5 g, when sonic sifting is employed.

The air jet sieving and sonic sieving methods may be useful for powders or granules when mechanical sieving techniques are incapable of giving a meaningful analysis.

These methods are highly dependent upon proper dispersion of the powder in the air current. This requirement may be hard to achieve if the method is used at the lower end of the sieving range (i.e., below 75 μm), when the particles tend to be more cohesive, and especially if there is any tendency for the material to develop an electrostatic charge. For the above reasons endpoint determination is particularly critical, and it is very important to confirm that the oversize material comprises single particles and is not composed of aggregates.

INTERPRETATION

The raw data must include the weight of test specimen, the total sieving time, and the precise sieving methodology and the set values for any variable parameters, in addition to the weights retained on the individual sieves and in the pan. It may be convenient to convert the raw data into a cumulative weight distribution, and if it is desired to express the distribution in terms of a cumulative weight undersize, the range of sieves used should include a sieve through which all the material passes. If there is evidence on any of the test sieves that the material remaining on it is composed of aggregates formed during the sieving process, the analysis is invalid.

■ 2S (USP28)